

Mist 運用マニュアル

アクセスポイント 再起動手順

ジュニパーネットワークス株式会社
2021年7月 Ver 1.0

JUNIPER 
driven by Mist AI


はじめに

- ❖ 本マニュアルは、『アクセスポイント 再起動手順』について説明します
- ❖ 手順内容は 2021年7月 時点の Mist Cloud にて確認を実施しております
実際の画面と表示が異なる場合は以下のアップデート情報をご確認下さい
<https://www.mist.com/documentation/category/product-updates/>
- ❖ 設定内容やパラメータは導入する環境や構成によって異なります
各種設定内容の詳細は下記リンクよりご確認ください
<https://www.mist.com/documentation/>
- ❖ 他にも多数の Mist 日本語マニュアルを「ソリューション & テクニカル情報サイト」に掲載しております
<https://www.juniper.net/jp/ja/local/solution-technical-information/mist.html>


- 運用ケース(例)
 - ・ アクセスポイントを再起動したい時

アクセスポイント 再起動

1. [Access Points] をクリックします



2. 対象のアクセスポイントを選択します



アクセスポイント 再起動

3. 左上のメニューから[Reboot APs] をクリックします
その後、[Reboot]をクリックすれば、アクセスポイントの再起動が開始されます

The screenshot displays the Mist management console interface. On the left is a navigation menu with options like Monitor, Marvis, Clients, Access Points, Switches, Gateways, and Location. The main content area shows the 'Access Points' page for site 'ABC_COMPANY'. It features summary statistics: 1 Access Point, 0 Wireless Clients, and 1 AP43. Below these are progress indicators for Connection Status (100%), VLANs (100%), and Version Compliance (0%). A 'Reboot APs' button is highlighted with a red box. A 'Confirm Reboot' dialog box is overlaid on the bottom right, asking 'Are you sure you want to reboot the selected Access Points?' and containing 'Reboot' and 'Cancel' buttons. A red dashed arrow points from the 'Reboot APs' button to the 'Reboot' button in the dialog.

Status	Name	MAC Address	Site
Connected	HQ-AP-02	d4:20:b0:c1:63:cd	ABC

Thank you

JUNIPER
driven by Mist AI 